

## FILTER BANK WITH 3" UNIT FILTER FRAME

### NOTES

1. FLOOR UNDER FILTER MUST BE LEVEL. STIFFENERS ARE REQUIRED WHEN BANK IS MORE THAN THREE HIGH; STIFFENERS EVERY TWO ROWS.
2. ALL CRACKS BETWEEN SEAMS TO BE FILLED WITH RTV SEALANT
3. STIFFENER PANELS RIVETED OR BOLTED BETWEEN FRAMES. FRAMES RIVETED OR BOLTED TOGETHER.
4. USE EACH FRAME CENTER DIMPLES FOR PROPER FILTER FRAME ALIGNMENT

